

```

classdef imageproject < matlab.apps.AppBase

    % Properties that correspond to app components
    properties (Access = public)

        % Callbacks that handle component events
        methods (Access = private)

            % Button pushed function: SELECTButton
            function SELECT(app, event)

                [file, path] = uigetfile('*.*.');
                if isequal(file,0)
                    figure(app.UIFigure);
                    return ;
                end

                figure(app.UIFigure);
                app.img = imread(fullfile(path,file));
                imshow(app.img, 'Parent', app.UIAxes);
                title(app.UIAxes, "INPUT IMAGE");
            end

            % Button pushed function: convert2grayButton
            function convert(app, event)

                app.img2 = rgb2gray(app.img);
                imshow(app.img2, 'Parent', app.UIAxes2);
                title(app.UIAxes2, "OUTPUT IMAGE");
            end
        end
    end
end

```

```
end
```

```
% Button pushed function: RESETButton
```

```
function reset(app, event)
```

```
    cla(app.UIAxes, 'reset'); % Clear all graphics objects and reset  
properties
```

```
    set(app.UIAxes, 'Visible', 'off'); % Optionally turn off visibility to  
indicate it's cleared
```

```
    cla(app.UIAxes2, 'reset');
```

```
set(app.UIAxes2, 'Visible', 'off');
```

```
cla(app.UIAxes3, 'reset');
```

```
set(app.UIAxes3, 'Visible', 'off');
```

```
end
```

```
% Button pushed function: pointenhancementButton
```

```
function histogram(app, event)
```

```
    grayImage = rgb2gray(app.img); % Ensure grayscale
```

```
% Convert image to double precision if necessary
```

```
if ~isa(grayImage, 'double')
```

```
    grayImage = im2double(grayImage); % Convert to double for processing
```

```
end
```

```
equalizedImage = histeq(grayImage);
```

```
% Display the equalized image
```

```
imshow(equalizedImage, 'Parent', app.UIAxes2);
```

```
% Display the histogram
```

```
figure;
```

```
imhist(equalizedImage);
```

```

title('Histogram of Equalized Image');

end

% Button pushed function: AverageButton

function average(app, event)

% Convert to grayscale if the image is RGB
if size(app.img, 3) == 3
    app.img = rgb2gray(app.img);
end

avg = fspecial('average');

% Applying the avg filter
favg = imfilter(app.img, avg, 'replicate');

imshow(favg, 'Parent', app.UIAxes2);
title(app.UIAxes2, "Average filter");

end

% Button pushed function: SharpningButton

function sharp(app, event)

if size(app.img, 3) == 3
    app.img = rgb2gray(app.img);
end

sharp = fspecial('unsharp');

fsharp = imfilter(app.img, sharp, 'replicate');

```

```

imshow(fsharp, 'Parent', app.UIAxes2);
title(app.UIAxes2, "Sharping filter");
end

% Value changed function: AddNoiseDropDown
function noise(app, event)
    value = app.AddNoiseDropDown.Value;
    % Callback function for dropdown menu to add noise

if size(app.img, 3) == 3
    grayImage = rgb2gray(app.img);
else
    grayImage = app.img;
end

% Add noise based on the selected type
switch value
    case 'Gaussian'
        noisyImage = imnoise(grayImage, 'gaussian', 0, 0.01);
    case 'Salt & Pepper'
        noisyImage = imnoise(grayImage, 'salt & pepper', 0.02);
    case 'Speckle'
        noisyImage = imnoise(grayImage, 'speckle', 0.04);
    case 'Uniform'
        noisyImage = grayImage + uint8(25 * (2 * rand(size(grayImage)) -
1));
    case 'Periodic'
        [rows, cols] = size(grayImage);
        periodicNoise = 64 * sin(2 * pi * 0.2 * (1:cols));
        noisyImage = grayImage + uint8(repmat(periodicNoise, rows, 1));

```

```

case 'Salt'

    noisyImage = grayImage;

    numSalt = round(numel(grayImage) * 0.02);

    saltIdx = randperm(numel(grayImage), numSalt); % Random
    noisyImage(saltIdx) = 255;

case 'Pepper'

    noisyImage = grayImage;

    numPepper = round(numel(grayImage) * 0.02);

    pepperIdx = randperm(numel(grayImage), numPepper); % Random
    noisyImage(pepperIdx) = 0;

otherwise

    noisyImage = grayImage; % invalid choise

end

imshow(noisyImage, 'Parent', app.UIAxes2);

title(app.UIAxes2, ['Image with ', value, ' Noise']);

app.noisyImage = noisyImage; % Store the noisy image


end


% Callback function

function log(app, event)


end


% Button pushed function: LogarithmButton

function Log(app, event)

if size(app.img, 3) == 3

```

```

        grayImage = rgb2gray(app.img);
    else
        grayImage = app.img;
    end

    % Set parameters
    sigma = 2.0;
    kernelSize = 2 * ceil(3 * sigma) + 1;

    % Create filter
    logFilter = fspecial('log', kernelSize, sigma);

    filteredImage = imfilter(double(grayImage) , logFilter, 'replicate');

    imshow(filteredImage, "Parent" , app.UIAxes2);
    title(app.UIAxes2, ['Logarithmic Filter']);
    end

    % Button pushed function: PowerlawButton
    function PowerLaw(app, event)
        if size(app.img, 3) == 3
            grayImage = rgb2gray(app.img);
        else
            grayImage = app.img;
        end

        gamma = 0.5;
        normalizedImage = double(grayImage) / 255;
        powerLawImage = normalizedImage .^ gamma;

        % Scale the result back to [0, 255] and convert to uint8
        powerLawImage = uint8(powerLawImage * 255);
    end

```

```

imshow(powerLawImage, "Parent", app.UIAxes2);
title(app.UIAxes2, ['Power Law Transformation']);
    end

    % Button pushed function: LaplacianButton
    function Laplacian(app, event)
        if size(app.img, 3) == 3
            grayImage = rgb2gray(app.img);
else
            grayImage = app.img;
end
        laplacianFilter = fspecial('laplacian', 0.2);
        % Apply filter
        filteredImage = imfilter(double(grayImage), laplacianFilter, 'replicate');
        imshow(filteredImage, "Parent", app.UIAxes2);
        title(app.UIAxes2, 'Laplacian Filter');
    end

    % Button pushed function: LaplacianofGaussianButton
    function LaplacianOfGaussian(app, event)
        if size(app.img, 3) == 3
            grayImage = rgb2gray(app.img);
else
            grayImage = app.img;
end
        sigma = 2.0;
        kernelSize = 2 * ceil(3 * sigma) + 1;
        % Gaussian filter
        gaussianFilter = fspecial('gaussian', kernelSize, sigma);
        % Laplacian filter
        laplacianFilter = fspecial('laplacian', 0.2); % 0.2 is the default alpha value
        % Apply Gaussian
        smoothedImage = imfilter(double(grayImage), gaussianFilter, 'replicate');

```

```

% Laplacian of Gaussian (LoG) filter
filteredImage = imfilter(smoothedImage, laplacianFilter, 'replicate');

imshow(filteredImage, "Parent", app.UIAxes2);
title(app.UIAxes2, 'Laplacian of Gaussian Filter');
    end

    % Button pushed function: MedianButton
    function median(app, event)
        if size(app.img, 3) == 3
            grayImage = rgb2gray(app.img);
        else
            grayImage = app.img;
        end
        filterSize = 3; % 3x3

        filteredImage = medfilt2(grayImage, [filterSize filterSize]);

        imshow(filteredImage, "Parent", app.UIAxes2);
        title(app.UIAxes2, 'Median Filter');
            end

            % Button pushed function: GaussianButton
            function Gaussian(app, event)
                if size(app.img, 3) == 3
                    grayImage = rgb2gray(app.img);
                else
                    grayImage = app.img;
                end

                sigma = 2.0;
                kernelSize = 2 * ceil(3 * sigma) + 1;

```



```

% Create filter
gaussianFilter = fspecial('gaussian', kernelSize, sigma);

% Apply Gaussian filter with correlation
correlatedImage = imfilter(double(grayImage), gaussianFilter, 'corr',
'replicate');

% Apply Gaussian filter with convolution
convolutionImage = imfilter(double(grayImage), gaussianFilter, 'conv',
'replicate');

imshowpair(correlatedImage, convolutionImage, 'montage');
title('Gaussian Filter: Correlation (left) and Convolution (right)');

end

% Button pushed function: GradientfilterButton
function Gradient(app, event)
    % Convert to grayscale if the image is RGB
    if size(app.img, 3) == 3
        grayImage = rgb2gray(app.img);
    else
        grayImage = app.img;
    end

    prewittFilterH = fspecial('prewitt'); % Horizontal Prewitt filter
    prewittFilterV = prewittFilterH';    % Vertical Prewitt filter

    sobelFilterH = fspecial('sobel');    % Horizontal Sobel filter
    sobelFilterV = sobelFilterH';        % Vertical Sobel filter

    prewittImageH = imfilter(double(grayImage), prewittFilterH, 'replicate');
    prewittImageV = imfilter(double(grayImage), prewittFilterV, 'replicate');

```

```

sobelImageH = imfilter(double(grayImage), sobelFilterH, 'replicate');
sobelImageV = imfilter(double(grayImage), sobelFilterV, 'replicate');

% Combine Horizontal and Vertical
prewittCombined = prewittImageH + prewittImageV;
sobelCombined = sobelImageH + sobelImageV ;

% Prewitt filters
subplot(2, 3, 1), imshow(prewittImageH, []), title('Prewitt (Horizontal)');
subplot(2, 3, 2), imshow(prewittImageV, []), title('Prewitt (Vertical)');
subplot(2, 3, 3), imshow(prewittCombined, []), title('Prewitt Filter');

% Sobel filters
subplot(2, 3, 4), imshow(sobelImageH, []), title('Sobel (Horizontal)');
subplot(2, 3, 5), imshow(sobelImageV, []), title('Sobel (Vertical)');
subplot(2, 3, 6), imshow(sobelCombined, []), title('Sobel Filter');
    end

    % Value changed function: LowpassDropDown
    function lowpassFourier(app, event)

        % Get the selected filter type from the dropdown
        value = app.LowpassDropDown.Value;

        % Convert to grayscale if the image is RGB
        if size(app.img, 3) == 3
            grayImage = rgb2gray(app.img);
        else
            grayImage = app.img;
        end

        % Perform Fourier Transform
        F = fft2(double(grayImage));

```

```

Fshift = fftshift(F);

% Get image size and create meshgrid for frequency domain
[M, N] = size(grayImage);
[x, y] = meshgrid(-floor(N/2):floor(N/2)-1, -floor(M/2):floor(M/2)-1);

% Set parameters for filters
D0 = 30;          % Cutoff frequency
n = 2;           % Order for Butterworth filter
filteredImage = grayImage; % Initialize in case of default

% Apply the selected filter
switch value
    case 'Ideal'
        % Ideal Low-Pass Filter
        idealFilter = double(sqrt(x.^2 + y.^2) <= D0);
        F_filtered = Fshift .* idealFilter;
        filteredImage = real(ifft2(ifftshift(F_filtered)));
        titleText = 'Ideal Low-Pass Filter';

    case 'Butterworth'
        % Butterworth Low-Pass Filter
        butterworthFilter = 1 ./ (1 + (sqrt(x.^2 + y.^2) / D0).^(2 * n));
        F_filtered = Fshift .* butterworthFilter;
        filteredImage = real(ifft2(ifftshift(F_filtered)));
        titleText = 'Butterworth Low-Pass Filter';

    case 'Gaussian'
        % Gaussian Low-Pass Filter
        gaussianFilter = exp(-(x.^2 + y.^2) / (2 * D0^2));
        F_filtered = Fshift .* gaussianFilter;
        filteredImage = real(ifft2(ifftshift(F_filtered)));
        titleText = 'Gaussian Low-Pass Filter';

```

```

        otherwise

            % Default to original image if unexpected value

            filteredImage = grayImage;

            titleText = 'Original Image';

        end

% Scale the intensity of the filtered image for display
filteredImage = mat2gray(filteredImage); % Normalize to [0, 1] range

% Display the filtered image in the specified UIAxes
imshow(filteredImage, 'Parent', app.UIAxes2);
title(app.UIAxes2, titleText);

end

% Value changed function: HighpassDropDown
function HighpassFourier(app, event)

    value = app.HighpassDropDown.Value;

% Convert to grayscale if the image is RGB
if size(app.img, 3) == 3
    grayImage = rgb2gray(app.img);
else
    grayImage = app.img;
end

% Perform Fourier Transform
F = fft2(double(grayImage));
Fshift = fftshift(F);

% Get image size and create meshgrid for frequency domain

```

```

[M, N] = size(grayImage);
[x, y] = meshgrid(-floor(N/2):floor(N/2)-1, -floor(M/2):floor(M/2)-1);

% High-Pass Filter Parameters
D0 = 30;          % Cutoff frequency for all filters
n = 2;           % Order for Butterworth filter

% Apply the selected high-pass filter
switch value
    case 'Ideal'
        % Ideal High-Pass Filter
        idealFilter = double(sqrt(x.^2 + y.^2) > D0);
        F_filtered = Fshift .* idealFilter;
        filteredImage = real(ifft2(ifftshift(F_filtered)));
        titleText = 'Ideal High-Pass Filter';

    case 'Butterworth'
        % Butterworth High-Pass Filter
        butterworthFilter = 1 ./ (1 + (D0 ./ sqrt(x.^2 + y.^2)).^(2 * n));
        F_filtered = Fshift .* butterworthFilter;
        filteredImage = real(ifft2(ifftshift(F_filtered)));
        titleText = 'Butterworth High-Pass Filter';

    case 'Gaussian'
        % Gaussian High-Pass Filter
        gaussianFilter = 1 - exp(-(x.^2 + y.^2) / (2 * D0^2));
        F_filtered = Fshift .* gaussianFilter;
        filteredImage = real(ifft2(ifftshift(F_filtered)));
        titleText = 'Gaussian High-Pass Filter';

    otherwise
        % In case of unexpected value, default to the original image
        filteredImage = grayImage;

```

```

        titleText = 'Original Image';

    end

    % Display the filtered image in the specified UIAxes
    imshow(filteredImage, 'Parent', app.UIAxes2);
    title(app.UIAxes2, titleText);

    end

    % Button pushed function: LaplacianFButton

    function LaplacianFourier(app, event)

    % Convert the image to grayscale if it is RGB
    grayImage = rgb2gray(app.img);

    % Transform to Fourier Domain
    Fshift = fftshift(fft2(double(grayImage)));

    % Create Laplacian Filter in Frequency Domain
    [M, N] = size(grayImage);
    [x, y] = meshgrid(-floor(N/2):floor(N/2)-1, -floor(M/2):floor(M/2)-1);
    laplacian = -(x.^2 + y.^2);
    laplacianFilter = laplacian / max(abs(laplacian(:))); % Normalize

    % Apply the Laplacian Filter
    filteredImage = real(ifft2(ifftshift(Fshift .* laplacianFilter)));
    filteredImage = mat2gray(filteredImage);

    % Add Filtered Image to Original
    enhancedImage = mat2gray(im2double(grayImage) + filteredImage);

    % Display Fourier Magnitude Spectrum
    figure;
    imshow(log(1 + abs(Fshift)), []);

```

```

title('Fourier Spectrum');

% Display Results in App
imshow(filteredImage, [], 'Parent', app.UIAxes3);
title(app.UIAxes3, 'Laplacian Filter Applied');
imshow(enhancedImage, [], 'Parent', app.UIAxes2);
title(app.UIAxes2, 'Original + Laplacian');

end

% Button pushed function: AliasingButton
function Aliasing(app, event)

% Convert the image to grayscale if it is RGB
if size(app.img, 3) == 3
    grayImage = rgb2gray(app.img);
else
    grayImage = app.img;
end

% Fourier Transform
F = fft2(double(grayImage));
Fshift = fftshift(F); % Shift zero frequency to the center

% Display the Spectrum
magnitudeSpectrum = log(1 + abs(Fshift)); % Compute the log of the magnitude
spectrum

% Show the Spectrum in a Figure
figure;
imshow(magnitudeSpectrum, []);
title('Fourier Aliasing Spectrum');

```

```

end

% Value changed function: RemoveNoiseDropDown
function noiseRemoval(app, event)

    value = app.RemoveNoiseDropDown.Value;

% Convert noisy image to double for filtering
imgdouble = double(app.noisyImage);

% Apply filter based on the selected type
switch value
    case 'Geometric mean'
        geometricMeanFilter = fspecial('average', [3 3]);
        filteredImage = exp(imfilter(log(imgdouble + 1),
geometricMeanFilter, 'replicate')) - 1;

    case 'Harmonic mean'
        filteredImage = 9 ./ imfilter(1 ./ (imgdouble + eps), ones(3, 3),
'replicate');

    case 'Contra-harmonic mean'
        Q = 1.5;
        filteredImage = imfilter(imgdouble.^(Q + 1), ones(3, 3),
'replicate')./ (imfilter(imgdouble.^Q, ones(3, 3), 'replicate') + eps);

    case 'Median'
        filteredImage = medfilt2(imgdouble, [3 3]);

    case 'Max'
        filteredImage = ordfilt2(imgdouble, 9, ones(3, 3));

    case 'Min'
        filteredImage = ordfilt2(imgdouble, 1, ones(3, 3));

```



```

    case 'Midpoint'

        maxFiltered = ordfilt2(imgdouble, 9, ones(3, 3));

        minFiltered = ordfilt2(imgdouble, 1, ones(3, 3));

        filteredImage = (maxFiltered + minFiltered) / 2;

    case 'Band reject'

%Fourier Transform

[M, N] = size(imgdouble);

F = fft2(imgdouble);

Fshift = fftshift(F);

noiseFrequencies = [0.2, -0.2];

harmonics = 1:3;

W = 2;

[X, Y] = meshgrid(-N/2:N/2-1, -M/2:M/2-1);

D = sqrt(X.^2 + Y.^2);

H = ones(size(Fshift));

for freq = noiseFrequencies

    for h = harmonics

        D0 = h * freq * min(M, N); % Harmonic distance from center

        H = H .* (1 ./ (1 + ((D .* W) ./ (D.^2 - D0^2 + eps)).^2));

    end

end

Ffiltered = Fshift .* H;

filteredImage = real(ifft2(ifftshift(Ffiltered)));

    otherwise

        filteredImage = imgdouble;

end

filteredImageNormalized = mat2gray(filteredImage);

```

```

% Display the normalized filtered image
imshow(filteredImageNormalized, 'Parent', app.UIAxes3);
title(app.UIAxes3, ['Filtered with ', value]);

end

% Button pushed function: ErosionButton
function erosion(app, event)

    % Convert the image to grayscale if it's RGB
    if size(app.img, 3) == 3
        grayImage = rgb2gray(app.img);
    else
        grayImage = app.img;
    end

    % Convert the image to binary
    binaryImage = imbinarize(grayImage, 0.5); % Adjust threshold as needed

    % Display the original binary image
    imshow(binaryImage, 'Parent', app.UIAxes3);
    title(app.UIAxes3, 'Original Binary Image');

    % Invert the binary image to expand black pixels
    binaryImage = ~binaryImage; % Invert the binary image

    % Create a structuring element
    se = strel('disk', 1 ); % Adjust size and angle as needed

    % Perform erosion
    erodedImage = imerode(binaryImage, se);
    erodedImage = imerode(erodedImage, se);

```

```

erodedImage = ~ erodedImage ;

% Display the eroded image
imshow(erodedImage, 'Parent', app.UIAxes2);
title(app.UIAxes2, 'Erosion Image');
end

% Button pushed function: DilationButton
function dilation(app, event)

    % Convert the image to grayscale if it's RGB
    if size(app.img, 3) == 3
        grayImage = rgb2gray(app.img);
    else
        grayImage = app.img;
    end

    % Convert the image to binary
    binaryImage = imbinarize(grayImage, 0.5); % Adjust threshold as needed

% Display the original binary image
    imshow(binaryImage, 'Parent', app.UIAxes3);
    title(app.UIAxes3, 'Original Binary Image');

% Invert the binary image to expand black pixels
    binaryImage = ~binaryImage; % Invert the binary image

% Create a large structuring element
    se = strel('disk', 3); % Disk with a large radius (e.g., 15)

% Perform dilation multiple times
    dilatedImage = imdilate(binaryImage, se); % First dilation
    dilatedImage = imdilate(dilatedImage, se); % Optional: Repeat if needed

```

```

% Invert the image back to restore original orientation
dilatedImage = ~dilatedImage;

% Display the dilated image
imshow(dilatedImage, 'Parent', app.UIAxes2);
title(app.UIAxes2, 'Dilated Image');
end

% Button pushed function: BoundaryExtractionButton
function BoundaryExtraction(app, event)

% Convert the image to grayscale if it's RGB
if size(app.img, 3) == 3
    grayImage = rgb2gray(app.img);
else
    grayImage = app.img;
end

% Convert to binary using a specified threshold
threshold = 0.4; % Adjust threshold between 0 and 1 if needed
binaryImage = imbinarize(grayImage, threshold);

% Create a structuring element for erosion
se = strel('disk', 1); % Small circular structuring element

% Perform erosion
erodedImage = imerode(binaryImage, se);

% Extract the boundary by subtracting the eroded image from the binary image
boundaryImage = binaryImage - erodedImage;

% Display the original binary image
imshow(binaryImage, 'Parent', app.UIAxes3);

```

```

title(app.UIAxes3, 'Original Binary Image');

% Display the boundary extracted image
imshow(boundaryImage, 'Parent', app.UIAxes2);
title(app.UIAxes2, 'Boundary Extracted Image');
end

% Button pushed function: ThresholdingButton
function Thresholding(app, event)

% Convert the image to grayscale if it is RGB
if size(app.img, 3) == 3
    grayImage = rgb2gray(app.img);
else
    grayImage = app.img;
end

normalizedThreshold = graythresh(grayImage);
optimalThreshold = normalizedThreshold * 255; % Convert to 8-bit scale
(0-255)

% Perform thresholding
segmentedImage = grayImage > optimalThreshold;

% Display the segmented image
imshow(segmentedImage, [], 'Parent', app.UIAxes2);

title(app.UIAxes2, ['Segmented Image (Threshold = '
num2str(round(optimalThreshold)) ' ')]);

end

% Button pushed function: EdgeDetectionButton

```

```

function SobelEdgeDet(app, event)

% Convert the image to grayscale if it is RGB
if size(app.img, 3) == 3
    grayImage = rgb2gray(app.img);
else
    grayImage = app.img;
end

edges = edge(grayImage, 'Sobel');

imshow(edges, [], 'Parent', app.UIAxes2);
title(app.UIAxes2, 'Sobel Edge Detection Segmentation');
end

% Button pushed function: AdaptiveButton
function AdaptiveThresholding(app, event)

% Convert the image to grayscale if it is RGB
if size(app.img, 3) == 3
    grayImage = rgb2gray(app.img);
else
    grayImage = app.img;
end

% Use adaptive thresholding to segment the image
adaptiveThresholdImage = adaptthresh(grayImage, 0.5); % Sensitivity
parameter '0.5'

binaryAdaptiveImage = imbinarize(grayImage, adaptiveThresholdImage); % Apply
the threshold

% Display Adaptive Thresholding Segmentation Result

```

```

imshow(binaryAdaptiveImage, [], 'Parent', app.UIAxes2);
title(app.UIAxes2, 'Adaptive Thresholding Segmentation');

end

% Button pushed function: PointDetectionButton
function pointDet(app, event)

% Convert the image to grayscale if it is RGB
if size(app.img, 3) == 3
    grayImage = rgb2gray(app.img);
else
    grayImage = app.img;
end

% ----- Point Detection using Laplacian of Gaussian
-----

% Use the Laplacian of Gaussian (LoG) method for point detection
pointDetectionImage = imfilter(double(grayImage), fspecial('log', 5, 1)); %
Kernel size: 5, Sigma: 1

% ----- Segmentation using Thresholding
-----

% Set a threshold for segmentation
threshold = 0.1; % Adjust threshold value as needed

segmentedImage = pointDetectionImage > threshold; % Apply thresholding to
the LoG response

% Display Point Detection Result (LoG response)
imshow(pointDetectionImage, [], 'Parent', app.UIAxes2);
title(app.UIAxes2, 'Point Detection (LoG)');

% Display Segmented Image (highlight points of interest)
imshow(segmentedImage, [], 'Parent', app.UIAxes3);

```

```

title(app.UIAxes3, 'Segmentation Based on Point Detection');

end

% Button pushed function: LineDetectionButton
function LineDet(app, event)

% Convert the image to grayscale if it is RGB
if size(app.img, 3) == 3
    grayImage = rgb2gray(app.img);
else
    grayImage = app.img;
end

% Step 1: Apply Sobel Filters in Specific Directions
horizontalEdges = edge(grayImage, 'Sobel', [], 'horizontal'); % Detect
horizontal lines
verticalEdges = edge(grayImage, 'Sobel', [], 'vertical'); % Detect vertical
lines

% Combine horizontal and vertical edges
combinedEdges = horizontalEdges | verticalEdges;

% Step 2: Segment the Image Using the Line Mask
segmentedImage = grayImage .* uint8(combinedEdges); % Use the mask directly
for segmentation

% Display Detected Edges (Horizontal and Vertical)
imshow(combinedEdges, [], 'Parent', app.UIAxes2);
title(app.UIAxes2, 'Line Detection (Horizontal + Vertical)');

% Display Segmented Image
imshow(segmentedImage, [], 'Parent', app.UIAxes3);
title(app.UIAxes3, 'Segmented Image Based on Detected Lines');

```



